

CUTLERY HOLDER. Designed for washing and storing cutlery. The cutlery should preferably be washed first without being sorted in the BRB cutlery basket and then washed again in the cutlery holders. Outer dimensions: Height 120 mm, ø 105.

| Part No. | Model |
|-----------|----------------|
| WD4550134 | Cutlery holder |